ORDER NO. SD7607-1100

Service Manual

FM/AM STEREO RECEIVER

SA-5560

(X), (XG), (XGH), (XSD), (XSW), (XE), (XAL)

TECHNICAL SPECIFICATIONS (IHF) Specifications are subject to change without notice for further improvement.

AMPLIFIER SECTION

1kHz continuous power:	both channels driven	108W + 108W (4Ω) 93W + 93W (8Ω)
20Hz ~ 20kHz continuous power:	both channels driven	90W + 90W (4Ω) 85W + 85W (8Ω)
Power bandwidth:	both channles driven at 8Ω	10Hz ~ 40kHz, −3dB
Total harmonic distortion:		0.1% at rated power (20Hz ~ 20kHz) 0.05% at half power (1kHz)
Intermodulation distortion:		0.1%
Damping factor.		55 (8Ω), 27.5 (4Ω)
Input sensitivity and impedance:	PHONO	2.5mV/47kΩ
	AUX, TAPE 2 PLAYBACK	150mV/35kΩ
	TAPE 1 PLAYBACK, REC/PLAY input	180mV/40kΩ
PHONO maximum input voltage:	(1kHz, RMS)	150mV
S/N (IHF, A):	PHONO	78 dB
	AUX	95dB
Frequency response:	PHONO	RIAA Standard curve ±0.2dB
	AUX	20Hz ~ 20kHz, ±0.5dB
Tone controls:	BASS	50Hz, +13dB ~ −13dB
	TREBLE	10kHz +12dB ~ −12dB
Loudness control (volume at −30dB):		50Hz, +9dB
Output voltage:	TAPE 1 REC OUT	180mV
	TAPE 2 REC OUT	150mV
	TAPE 1 REC/PLAY output	30mV
High fillter:		7kHz −6dB/oct.
Low filter:		100Hz, −6dB/oct.

FM TUNER SECTION

Frequency range:				88 ~ 108MHz
Antenna terminals:		300Ω (balanced)		75Ω (unbalanced)
Sensitivity:				1.8μV
Total harmonic distortion.	MONO	0.15%	STEREO	0.25%
S/N:	MONO	75dB	STEREO	72dB
Frequency response:		20Hz ~ 15kHz, +0.2dB −0.8dB		
Alternate channel selectivity:				70dB
Capture ratio:				1.5dB
Image rejection at 98MHz:				53dB
IF rejection at 98MHz:				80dB
AM suppression:				55dB
Stereo separation:	1kHz	45dB	10kHz	35dB
Leak carrier:		−65dB (19kHz)		−75dB (38kHz)

AM TUNER SECTION

Frequency range:	525 ~ 1605kHz
Sensitivity:	30μV, 260μV/m
Selectivity:	22dB
Image rejection at 1000kHz:	47dB
IF rejection at 1000kHz:	40dB

GENERAL

Power consumption:	650W
Power supply:	110V/120V/220V/240V
Dimensions (W x H x D)	500 x 150 x 420mm (19-11/16" x 5-29/32 x 16-17/32")
Weight:	16kg (35 3.b.)

TECHNISCHE DATEN (DIN 45 500) Spezifikationen können infolge von Verbesserungen ohne Ankündigung geändert werden.

VERSTÄRKERTEIL

RMS-Dauertonleistung bei 1kHz:		
beide Kanäle zusammen ausgesteuert		2 x 108W (4Ω) 2 x 93W (8Ω)
RMS-Dauertonleistung bei 20Hz ~ 20kHz:		
beide Kanäle zusammen ausgesteuert		2 x 90W (4Ω) 2 x 85W (8Ω)
Leistungsbandbreite (beide Kanäle zusammen ausgesteuerbei 4Ω):		10Hz ~ 40kHz, −3dB
Harmonische Verzerrungen:		
Nennleistung bei 40Hz ~ 16,000Hz, 4Ω		0.1%
Intermodulationsverzerrung:		
Nennleistung bei 250Hz: 8000Hz = 4 : 1 4Ω		0.1%
Dämpfungsfaktor:		55 (8Ω), 27.5 (4Ω)
Eingangsempfindlichkeit & Impedanz:	PHONO	2.5mV/47kΩ
	AUX, TAPE 2 PLAYBACK	150mV/35kΩ
	TAPE 1 PLAYBACK, REC/PLAY Wiedergabe	180mV/40kΩ
PHONO Maximale Eingangsspannungen: (1kHz RMS)		150mV
Fremdspannungsabstand:	Nennleistung PHONO	65dB
	AUX	80dB
	50mW Ausgangsleistung PHONO	50dB
	AUX	50dB
Frequenzgang:		20Hz ~ 20kHz, ±0.5dB
Klangregler:	BÄSSE	50Hz, +13dB ~ −13dB
	HÖHEN	10kHz, +12dB ~ −12dB
Gehörgerechte Lautstärkekorrektur (Lautstärke −30dB):		50Hz, +9dB
Ausgangsspannungen:	TAPE 1 REC OUT	180mV
	TAPE 1 REC/PLAY Aufnahme	30mV
	TAPE 2 REC OUT	150mV
Hochtonfilter:		7kHz, −6dB/oct.
Tieftonfilter:		100Hz, −6dB/oct.

UKW-TUNERTEIL

Empfangsbereich:				88 ~ 108MHz
Antennenanschluss:	300Ω (symmetrisch)		75Ω (asymmetrisch)	
Empfindlichkeit:	1.8μV, 30dB Fremdspannungsabstand			300Ω
	1.5μV, 20dB Fremdspannungsabstand			300Ω
	1.3μV, 30dB Fremdspannungsabstand			75Ω
	0.9μV, 20dB Fremdspannungsabstand			75Ω
Harmonische Verzerrung.	MONO	0.15%	STEREO	0.25%
Fremdspannungsabstad	MONO	56dB	STEREO	54dB
Frequenzgang:		20Hz ~ 15kHz, +0.2dB, -0.8dB		
Selektivität:				70dB
Gleichwellen-Selektion:				1.5dB
Spiegelselektion bei 98MHz:				53dB
ZF-Festigkeit bei 98MHz:				80dB
AM-Unterdrückung:				55dB
Stereo Übersprechdämpfung:		45dB bei 1kHz, 35dB bei 10kHz		
Trägerrest (19kHz, 30kHz):		−65dB bei 19kHz, −75dB bei 38kHz		
Begrenzung, Einsatzpunkt:				1.0μV
Bandbreite:	ZF-Verstäker			50kHz
	UKW-Demodulator			100kHz

AM-TUNERTEIL

Empfangsbereoich:	525 ~ 1605kHz
Empfindlichkeit:	30μV, 26μV/m
Selektivität:	22dB
Spiegelselektion bei 1000kHz:	47dB
ZF-Festigkeit bei 1000kHz:	40dB

ALLGEMEINE DATEN

Leistungsaufnahme:	650W
Netzspannung umschaltbar:	110V/120V/220V/240V
Abmessungen (B x H x T):	500 x 150 x 420mm
Gewicht:	16kg

Technics

Matsushita Electric Trading Co., Ltd.
P.O. Box 288, Central Osaka Japan

■ LOCATION OF CONTROLS



① POWER SWITCH
② BASS CONTROL
③ TREBLE CONTROL
④ BALANCE CONTROL
⑤ VOLUME CONTROL
⑥ FM TUNING METER
⑦ FM/AM SIGNAL METER
⑧ FM STEREO INDICATOR
⑨ TUNING CONTROL
⑩ HEADPHONES JACK
⑪ MAIN SPEAKER SWITCH
⑫ REMOTE SPEAKER SWITCH
⑬ LOW FILTER SWITCH
⑭ HIGH FILTER SWITCH
⑮ LOUDNESS SWITCH
⑯ FM MUTING SWITCH
⑰ FM HI-BLEND SWITCH
⑱ MODE SWITCH
⑲ TAPE MONITOR (TAPE 1) SWITCH
⑳ TAPE MONITOR (TAPE 2) SWITCH
㉑ SELECTOR SWITCH



㉒ FM ANTENNA TERMINALS (300Ω)
㉓ FM ANTENNA TERMINALS (75Ω)
㉔ AM ANTENNA TERMINAL
㉕ 4CH MPX OUTPUT TERMINAL
㉖ REC/PLAY (TAPE 1) SOCKET
㉗ GROUND TERMINAL
㉘ PHONO INPUT TERMINALS
㉙ AUX INPUT TERMINALS
㉚ TAPE DECK 2 CONNECTION TERMINALS
㉛ TAPE DECK 1 CONNECTION TERMINALS
㉜ SPEAKER CIRCUIT PROTECTION FUSES
㉝ MAIN SPEAKER TERMINALS
㉞ REMOTE SPEAKER TERMINALS
㉟ VOLTAGE ADJUSTER (Except Set for Australia [XAL])



■ BLOCK DIAGRAM



■ DIAL CORD INSTALLATION GUIDE

1. Dial cord length is 91¼" (230cm).
2. Tuning gang is positioned at maximum capacity. (Frequency is minimum)
3. Arrow marks (1 ~ 8) indicated correct order and direction of stringing dial cord.



■ TO REMOVE CABINET

1. Loosen two (2) metal clamp-mounting screws, nos. ① and ② as shown in fig. 1.
2. Remove four (4) cabinet-mounting screws, nos. ③ ~ ⑥ as shown in fig. 2.
3. Remove cabinet from chassis in arrow direction 1 to 2, as shown in fig. 2.
4. To reassemble, reverse above procedure.

Fig. 1



Fig. 2

■ SERVICE AID

• FM soft muting

When moving the tuning point away from the point of maximum output (optimum tuning) the signal output gradually decreases until it reaches zero output. (between stations.) In conventional muting circuits a sharp "popping" noise is heard when tuning, due to the sudden (switch-like) action of the muting circuit from zero signal to full output. This "Soft muting" circuit lets the sound fade more gradually, making it more natural and pleasant to listen to.



Without muting



Conventional muting



Soft muting

• Circuitry principles

This circuit makes use of the VBE characteristics of TR102 (2SC828). (Refer to fig. 1.) The detected voltage from the FM IF input signal is applied to the base of TR102. When the FM input signal increases this voltage increases, causing the emitter current, to increase, which, in turn, decreases the collector voltage of TR102, making the collector voltage approache ground potential. Because the collector of TR102 is connected to the IC101 IF amplifier through the muting switch, a change in the collector voltage will control the output of the IC101 IF amplifier. When the FM input signal increases to the point that the base voltage of TR102 reaches its operating point (about 0.6V), the output of IC101 reaches maximum.





VBE curve of TR102

Fig. 1.



FM input vs. AF output curve

Fig. 2

■ FM RF ALIGNMENT INSTRUCTIONS . . . . . Only Set for Germany

ABGLEICHANWEISUNGEN.....VOR DEM ABGLEICH SORGFÄLTIG DURCHLESEN					
MESSENDER		SKALENZEIGER-EINSTELLUNG DES EMPFÄNGERS [ABSTAND]	ANGEIGE (RÖHRENVOLTMETER ODER OSZILLOGRAPH)	ABGLEICH	BEMERKUNGEN
SCHALTUNG	FREQUENZ				
FM HF-ABGLEICH					
Anschluß an den FM Antennenanschluß über die künstliche. FM Antenne (Vgl. Abb. 1)	87.5MHz (100% Mod bei 400Hz)	87.5MHz [0mm]	Output meter über Lautsprecher-schwingspule anschließen.	L5 (Oszillatorspule)	Auf max. Ausgang abgleichen
〃	90MHz (〃)	90MHz (17.2mm)	〃	L3 (Zwischenkreis) L2 (Antennenspule)	〃
〃	106MHz (〃)	106MHz (174.1mm)	〃	CT3 (OSZ. Trimmer) CT2 (DET. Trimmer) CT1 (ANT. Trimmer)	〃

■ ALIGNMENT INSTRUCTIONS

MAIN AMP (IcQ) ALIGNMENT

Notes:
1. The "IcQ" adjustment should be started about 5 minutes after setting the power switch to the ON position.
2. Speakers switch to OFF position.

1

1 Connect DC VTVM between TP602 and TP603 (Left channel), TP604 and TP605 (Right channel)
2 Adjust VR601 (Left channel) and VR602 (Right channel) to 12mV on DC VTVM indication.

Notes:
1. Muting switch ..... OFF
2. Band selector switch.....AM/FM AUTO (FM, RF, FM-IF)
3. 300Ω FM dummy antenna.....Refer to fig. 3.
4. Speaker switch.....ON
5. Mode switch..... MONO
6. Maintain line voltage at rated voltage.
7. Output of signal generator should be no higher than necessary to obtain an output reading.

	SIGNAL GENERATOR or SWEEP GENERATOR		DIAL SETTING [DISTANCE]	INDICATOR (VTVM or SCOPE) (DISTORTION METER)	ADJUSTMENT POINTS	REMARKS
	CONNECTION	FREQUENCY				
	AM ALIGNMENT					
2	High side through 0.001μF to **AM** antenna trimmer terminal. Common to chassis.	455kHz (Set for England to 470KHz)	Point of non-inter-ference	Connect vertical amplifier of scope to **TP1.** through 0.1μF.	T1 (1st IFT) (P) T2 (2nd IFT) (S) T3 (IF Trap)	Adjust for maximum output.
3	Fashion loop of several turns of wire and radiate signal into loop of tuner.	600kHz (30% Mod. with 400Hz)	600kHz [1⅛" (31.5mm)]	Connect VTVM or scope to speaker terminal of receiver.	L6 (OSC Coil) L8 (ANT Coil)	Adjust for maximum output, Adjust L8 by moving coil bobbin. along ferrite core.
4	Fashion loop of several turns of wire and radiate signal into loop of tuner.	1500kHz (30% Mod. with 400Hz)	1500kHz [7⅜" (180.1mm)]	Connect VTVM or scope to speaker terminal of receiver.	CT5 (OSC Trimmer) CT4 (ANT Trimmer)	Adjust for maximum output. Repeat steps (3) and (4).
	FM-IF ALIGNMENT					
5		No Signal	Point of non-inter-ference.	Tuning meter of set.	T101 (DISCRI IFT)(A) Orange Core	Adjust for center position of tuning meter.
	FM-RF ALIGNMENT					
6	Connect to FM antenna terminal through FM dummy antenna.	90MHz (100% Mod. with 400Hz)	90MHz [¾" (19.2mm)]	Connect VTVM or scope to speaker terminal of receiver.	L5 (OSC Coil) L3 (DET Coil) L2 (ANT Coil)	Adjust for maximum output.
7	Connect to FM antenna terminal through FM dummy antenna.	106MHz (100% Mod. with 400Hz)	106MHz [6¹⁵⁄₁₆" (176.2mm)]	Connect VTVM or scope to speaker terminal of receiver.	CT3 (OSC Trimmer) CT2 (DET Trimmer) CT1 (ANT Trimmer)	Adjust for maximum output. Repeat steps (6) and (7).
	FM MONO DISTORTION ALIGNMENT					
8	Connect to FM antenna terminal through FM dummy antenna.	100MHz (100% Mod. with 400Hz)	100MHz	Connect distortion meter to speaker terminal of receiver.	T101 (DISCRI IFT)(B) Green Core	Adjust for minimum distortion meter indication.

FM SIGNAL METER ALIGNMENT

9

① Apply 100MHz FM signal of 100 dB, 400Hz 30% modulation to FM antenna terminal through FM dummy antenna.
② Tuning 100MHz for maximum output by speaker terminal.
③ Adjust **VR104** for about 4.7 point of signal meter indication.

SOFT MUTING LEVEL ALIGNMENT ..... Refer to SERVICE AID on page 4.

10

① Muting switch to "off".
② Apply a 60 dB (1mV) mono RF FM signal to the antenna terminals.
③ Adjust Volume Control of receiver to indicate 0 dB on meter across speaker terminals.
④ Muting switch to "on".
⑤ Reduce FM signal to 19 dB (9μV).
⑥ Adjust **VR101** to **–3 dB** on output meter. Refer to fig. 6.

FM MPX PILOT ALIGNMENT

11

Using a frequency counter	Using alternate system
① 98MHz Non-modulated mono signal applied to set. ② Muting switch to "on". ③ Connect frequency counter to **TP101** through resistor (100kΩ). ④ Adjust **VR102** to 19kHz ±30Hz.	① Apply stereo signal from generator or stereo station to receiver. ② Adjust **VR102** until stereo indicator lights up. Cement arm of **VR102** as shown in fig. 4.

STEREO SEPARATION ALIGNMENT

Note: 1. Stereo modulator ..... Connect stereo modulator output to EXT. MOD. terminal of signal generator. Internal OSC..... 1kHz Pilot signal modulation..... 10%
2. Signal generator ..... Frequency approximately 98MHz. Output level 72 dB (IHF). Modulation mode to FM.
3. Band selector switch..... FM AUTO 4. Mode switch..... STEREO

	SIGNAL GENERATOR CONNECTION	STEREO MODULATOR MODE and MOD. RATE	INDICATOR (VTVM or SCOPE)	ADJUSTMENT POINTS	REMARKS
12	FM antenna terminal through dummy antenna.	L (and R) 30% Modulation.	Connect VTVM or scope to speaker terminals through low pass filter. Refer to fig. 5.	VR103	Adjust for minimum right (and left) output.

● **Alignment Points** (FM/AM RF & IF Circuit)





300Ω FM Dummy Antenna

Fig. 3



Ⓐ ~ Ⓑ, Ⓓ ~ Ⓔ : Stereo OFF Position
Ⓑ ~ Ⓓ : Stereo ON Position (Indicator Lighting)
Ⓒ : Adjust Point of Pilot Circuit.

Fig. 4

● **Alignment Points** (AF Amplifier Circuit)





Fig. 5



FM input vs. AF output curve

Fig. 6

● **Dial Scale and Start Point of Dial Pointer**



■ BLOCK DIAGRAM OF INTEGRATED CIRCUIT

- IC1 (SVIHA1151)
  AM RF, OSC, MIX, IF AMP &
  AM DETECTOR CIRCUIT



- IC102 (SVIHA1156)
  FM MULTIPLEX CIRCUIT



- IC101 (SVILA1230)
  FM IF AMP, FM DETECTOR & MU TING CIRCUIT



- IC201, 202 (SVITA7129P)
  EQUALIZER AMPLIFIER



■ POWER TRANSISTOR CIRCUIT BOARD



■ SPEAKERS TERMINAL CIRCUIT BOARD



■ INPUT & TAPE DECK CONNECTION TERMINAL CIRCUIT BOARD



■ SPEAKER PROTECTION CIRCUIT . . . . . Only Set for England (XE)

- Printed Circuit Board



- Schematic Diagram



Schematic Diagram.....Model SA-5560 (X), (XG), (XGH), (XSD), (XSW)

(This schematic diagram may be modified at any time w



Notes:

1. **S1001-1～S1001-4:** Selector switch in **"FM AUTO"** position.
   ①AM ←→ ②FM AUTO ←→ ③PHONO ←→ ④AUX
2. **S1001:** Tape monitor (TAPE 1) switch in **"SOURCE"** position.
3. **S1003:** Tape monitor (TAPE 2) switch in **"SOURCE"** position.
4. **S1004:** Mode switch in **"STEREO"** position.
5. **S1005:** FM hi-blend switch in **"OFF"** position.
6. **S1006:** FM muting switch in **"ON"** position.
7. **S1007:** Loudness switch in **"OFF"** position.
8. **S1008:** Low filter switch in **"OFF"** position.
9. **S1009:** High filter switch in **"OFF"** position.
10. **S1010:** Power switch in **"ON"** position.
11. **S1011:** Main speaker switch in **"ON"** position.
12. **S1012:** Remote speaker switch in **"OFF"** position.
13. **S1013-1, S1013-2:** Voltage selector switch in "110V" position.
    ①110V ←→ ②120V ←→ ③220V ←→ ④240V
14. **VR101:** FM muting level adjustment
15. **VR102:** FM MPX voltage control oscillator (VCO) adjustment
16. **VR103:** FM separation adjustment
17. **VR104:** FM signal meter adjustment
18. **VR501:** Bass control
19. **VR502:** Treble control
20. **VR601, 602:** Power transistor I_{CQ} adjustment
21. **VR1001:** Volume control
22. **VR1002:** Balance control
23. DC voltage measureme
    [ ] ..... FM/
    < > ..... FM
    ( ) ..... FM

nay be modified at any time with the development of new technology)



23. DC voltage measurements are taken with DC voltmeter from chassis ground.
    - [ ] ..... FM/AM non signal condition
    - < > ..... FM stereo signal reception
    - ( ) ..... FM muting to "ON" position

IMPORTANT SAFETY NOTICE

THE SHADED AREA ON THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR SAFETY.
WHEN SERVICING IT IS ESSENTIAL THAT ONLY MANUFACTUR'S SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SHADED AREAS OF THE SCHEMATIC.

■ EQUALIZER, TONE CONTROL, MAIN AMPLIFIER, SPEAKER PROTECTION & POWER SUPPLY CIRCUIT BOARD



IC201, 202 (SVITA7129P)

AF EQUALIZER AMP	
1	2.2 V
2	0.6 V
3	0.1 V
4	0 V
5	0.8 V
6	18.1 V
7	33.8 V

TR103, 104 (2SA733)

AF AMP	
E	11.8 V
C	6.9 V
B	11.2 V

TR105 (2SC1398)

REGULATOR	
E	13.5 V
C	21.5 V
B	14.1 V

TR106 (2SC828)

REGULATOR	
E	12.3 V
C	13.5 V
B	13 V

TR108 (2SC828)

SWITCHING	
E	0 V
C	0 V
B	0 V

TR501, 502 (2SC1327)

TONE AMP	
E	1.1 V
C	13.5 V
B	1.7 V

TR503, 504 (2SC1328)

TONE AMP	
E	3 V
C	20.6 V
B	3.6 V

TR601, 602 (2SA798)

DEIFFRENTIAL	
E	0.6 V
B1	0 V
B2	0 V
C1	-52.1 V
C2	-52.1 V

TR603, 604 (2SC1628)

PRE DRIVE	
E	-53.5 V
C	-1.1 V
B	-52.1 V

TR605, 606 (2SC828)

THERMO COMP.	
E	-1.2 V
C	1.2 V
B	-0.4 V

TR607, 608 (2SD381)

DRIVE	
E	0.6 V
C	54.2 V
B	1.2 V

TR609, 610 (2SB536)

DRIVE	
E	-0.6 V
C	-54.2 V
B	-1.2 V

TR611, 612 (2SC1116)

POWER	
E	0.01 V
C	54.2 V
B	0.6 V

TR613, 614 (2SA747)

POWER	
E	-0.01 V
C	-54.2 V
B	-0.6 V

TR615 (2SC828)

SWITCH	
E	0 V
C	1.2 V
B	-1 V

TR616 (2SC828)

SWITCH	
E	0 V
C	1.2 V
B	0 V

TR617 (2SC1509)

RELAY DRIVE	
E	0.6 V
C	3.0 V
B	1.2 V

TR618 (2SC1509)

RELAY DRIVE	
E	0 V
C	3.0 V
B	0.6 V

OWER SUPPLY CIRCUIT BOARD



VOLUME CONTROL | BALANCE CONTROL | HIGH FILTER SWITCH | LOW FILTER SWITCH | TREBLE CONTROL | BASS CONTROL

TR601,602 (2SA798) DEIFFRENTIAL

E	0.6 V
B1	0 V
B2	0 V
C1	-52.1 V
C2	-52.1 V

TR603,604 (2SC1628) PRE DRIVE

E	-53.5 V
C	-1.1 V
B	-52.1 V

TR605,606 (2SC828) THERMO COMP.

E	-1.2 V
C	1.2 V
B	-0.4 V

TR607,608 (2SD381) DRIVE

E	0.6 V
C	54.2 V
B	1.2 V

TR609,610 (2SB536) DRIVE

E	-0.6 V
C	-54.2 V
B	-1.2 V

TR611,612 (2SC1116) POWER

E	0.01 V
C	54.2 V
B	0.6 V

TR613,614 (2SA747) POWER

E	-0.01 V
C	-54.2 V
B	-0.6 V

TR615 (2SC828) SWITCH

E	0 V
C	1.2 V
B	-1 V

TR616 (2SC828) SWITCH

E	0 V
C	1.2 V
B	0 V

TR617 (2SC1509) RELAY DRIVE

E	0.6 V
C	3.0 V
B	1.2 V

TR618 (2SC1509) RELAY DRIVE

E	0 V
C	3.0 V
B	0.6 V

TR701 (2SC1328) RIPPLE FILTER

E	42 V
C	43.1 V
B	42.7 V

■ FM RF, FM IF AMPLIFIER, FM MPX & AM CIRCUIT BOARD



IC1 (SVIHA1151)

AM RF, OSC, MIX, IF, DET			
1	1 V	8	6.6 V
2	11.7 V	9	0 V
3	6.5 V	10	11.4 V
4	11.7 V	11	1.7 V
5	3.5 V	12	0.7 V
6	1.3 V	13	1.5 V
7	2.1 V	14	0 V

IC101 (SVILA1230)

FM IF AMP. DISCRI			
1	2.7 V	10	5.8 V
2	2.7 V	11	11.2 V
3	2.7 V	12	4 V
4	0 V	13	0 V
5	5.6 V	14	0 V
6	5.8 V	15	4.9 V
7	5.8 V	16	0 V
8	5.8 V		
9	5.8 V		
5	MUTING ON		1.4 V
	MUTING OFF		0 V

IC102 (SVIHA1156W)

	FM	MPX
	STEREO	MONO
1	13.1 V	13.1 V
2	3 V	3 V
3	5.1 V	5.1 V
4	9.5 V	9.5 V
5	9.5 V	9.5 V
6	0.9 V	12.7 V
7	0 V	0 V
8	2.4 V	0.3 V
9	2.3 V	2.3 V
10	1.5 V	1.5 V
11	2.2 V	2.2 V
12	2.3 V	2.3 V
13	2.3 V	2.3 V
14	1.8 V	1.8 V

TR107 (2SC828) SWITCHING

	STEREO	MONO
E	0 V	0 V
C	2.4 V	0.3 V
B	0 V	0.6 V

TR1 (3SK40) FM RF

S	0 V
D	10 V
G1	0 V
G2	3.8 V

TR2 (2SC1674) FM MIX

E	1 V
C	11.5 V
B	1.7 V

TR3 (2SC1675) FM OSC

E	2.9 V
C	10.4 V
B	3.6 V

TR4 (2SC828) SWITCHING

E	0 V
C	0 V
B	0 V

TR101 (2SC1675) FM IF

E	3.1 V
C	10.4 V
B	3.8 V

TR102 (2SC828) MUT. SWITCH

	OFF	ON
E	0 V	0 V
C	8.4 V	0.1 V
B	0 V	6 V

■ CIRCUIT OF POWER SUPPLY

• Set for England (XE)



• Set for Australia (XAL)



Note: [S] indicates that only parts specified by the manufacture be used for replacement in critical circuits.

■ REPLACEMENT PARTS LIST

Important Safety Notice

Components identified by shaded area have special characteristics important for safety. When replacing any of these components use only manufacturer's specified parts.

NOTE: 1. Part numbers are indicated on most mechanical parts.
Please use this part number for parts orders.

Ref. No.	Part No.	Part Name & Description	Per Set		Remarks
		INTEGRATED CIRCUITS			
IC1	SVIHA1151	AM RF, IF Amplifier Mix, Osc & Det	1		
IC101	SVILA1230	FM IF Amplifier & Discriminator	1		
IC102	SVIHA1156W	FM MPX	1		
IC201, 202	SVITA7129P	Equalizer Amplifier	2		
		TRANSISTORS			
TR1	3SK40-M	FM RF Amplifier [FET]	1		
TR2	2SC1674-M	FM Mixer	1		
TR3, 101	2SC1675-L1	FM Oscillator & IF Amplifier	2		
TR4, 102, 106 107, 108, 501 502, 503, 504, 615, 616, 619, 701	**2SC1328-T**	Switching, Tone Amplifier, Ripple Filter & Speakers Protection (in ranks S or T).	13		
TR103, 104	2SA733-P1	AF Amplifier	2		
TR105	2SC1398-Q	Regulator, (ranks Q or R)	1		
TR601, 602	2SA798A-G2	Differential Amplifier (ranks F2 or G2)	2		
TR603, 604	2SC1628-0	Pre Drive Amplifier (ranks O or Y)	2		
TR605, 606	**2SC828A-R**	Thermo Compensation	2		
TR607, 608	2SD381A-L9	Driver Amp } Use in pair ranks (L or M)	2		O
TR609, 610	2SB536A-L9	Driver Amp }	2		O
TR611, 612	2SC1116A-0	Power Amp } Use in pair ranks (O or Y)	2		O
TR613, 614	2SA747A-0	Power Amp }	2		O
TR617, 618	**2SC1509F-Q**	Relay Driver (in ranks Q or R)	2		
TR620	**2SA902-F**	Speaker Protection Switching	1		
		Note: TR619 and TR620, Use only set for England [XE].			
		DIODES			
D101, 102	OA90	AGC	2		
D103, 104, 105, 106, 108, 110, 111	MA150	Muting Switching	7		
D107	SVDMZ414	14V Zener, Voltage Stabilizer	1		O
D109	SVDMA26-2	Varistor	1		
D601	SVDMZ324	24V Zener, Voltage Stabilizer	1		O
D602, 603, 702, 703	SVD10E1	Rectifier	4		
D701	SVD6B6CTA-2	Rectifier	1		
		COILS and TRANSFORMERS			
L1	SLAA4W1-3	Balun Coil	1		
L2	SLAA4N9	FM Antenna Coil	1		
L3	SLDA4N18	FM Detector Coil	1		
L4	ELQ5A77	Choke Coil	1		
L5	SLOA4N9	FM Oscillator Coil	1		
L6	RLO2M4P	AM Oscillator Coil	1		
L7	SLI2M401	AM IF Filter Coil	1		
L8	SLF2D27	AM Antenna Coil	1		

Ref. No.	Part No.	Part Name & Description	Per Set		Remarks
L101	SLQX180-1	Choke Coil	1		
L102	SLMA1Z3-K	Low Pass Filter	1		
T1	RLI2M201	AM IF Transformer	1		
T2	RLI2M202	AM IF Transformer	1		
T101	SLI4D513	FM IF Transformer	1		
T1001 [XAL]	SLT5S19	Power Transformer, Set for [XAL]	1		O
T1001 [X, XG, XGH, XE, XSD, XSW]	SLT5S15	Power Transformer, Set for [X], [XG], [XGH], [XE], [XSD] & [XSW]	1		O
		CERAMIC FILTERS			
CF101, 102, 103	SVFE107MA8A	FM IF Circuit, Red. 10.7MHz	each 3		
	SVFE107MA8B	FM IF Circuit, Blue, 10.67MHz			
	SVFE107MA8C	FM IF Circuit, Orange, 10.73MHz			
	SVFE107MA8D	FM IF Circuit, Black, 10.64MHz			
	SVFE107MA8E	FM IF Circuit, White, 10.76MHz			
	(Use pair ranks as same as	CF101, 102, and CF103)			
		THERMISTORS			
TH601, 602	RRT251	Thermistor, Drive Amplifier Circuit	2		
		POSISTOR			
PH601 [XE]	SRP4BC60158	Posistor, Only set for England [XE]	1		
		RESISTORS			
R1	**ERD25TJ104**	100kΩ, 1/4W, ± 5% Carbon	1		
R2	**ERD25TJ470**	47Ω, 1/4W, ± 5% Carbon	1		
R3	**ERD25TJ151**	150Ω, 1/4W, ± 5% Carbon	1		
R4	**ERD25TJ473**	47kΩ, 1/4W, ± 5% Carbon	1		
R5	**ERD25TJ822**	8.2kΩ, 1/4W, ± 5%, Carbon	1		
R6	**ERD25TJ102**	1kΩ, 1/4W, ± 5%, Carbon	1		
R7	**ERD25TJ331**	330Ω, 1/4W, ± 5%, Carbon	1		
R8	**ERD25TJ470**	47Ω, 1/4W, ± 5%, Carbon	1		
R9	**ERD25TJ102**	1kΩ, 1/4W, ± 5%, Carbon	1		
R10	**ERD25TJ223**	22kΩ, 1/4W, ± 5%, Carbon	1		
R11	**ERD25TJ123**	12kΩ, 1/4W, ± 5%, Carobn	1		
R12	**ERD25TJ182**	1.8kΩ, 1/4W, ± 5%, Carbon	1		
R13	**ERD25TJ471**	470Ω, 1/4W, ± 5%, Carbon	1		
R14	**ERD25TJ682**	6.8kΩ, 1/4W, ± 5%, Carbon	1		
R15	**ERD25TJ331**	330Ω, 1/4W, ± 5%, Carbon	1		
R16	**ERD25TJ222**	2.2kΩ, 1/4W, ± 5%, Carbon	1		
R17	**ERD25TJ103**	10kΩ, 1/4W, ± 5%, Carbon	1		
R18	**ERD25TJ103**	10kΩ, 1/4W, ± 5%, Carbon	1		
R19	**ERD25TJ473**	47kΩ, 1/4W, ± 5%, Carbon	1		
R20	**ERD25TJ102**	1kΩ, 1/4W, ± 5%, Carbon	1		
R21	**ERD25TJ221**	220Ω, 1/4W, ± 5%, Carbon	1		
R22	**ERD25TJ104**	100kΩ, 1/4W, ± 5%, Carbon	1		
R101	**ERD25TJ151**	150Ω, 1/4W, ± 5%, Carbon	1		
R102	**ERD25TJ332**	3.3kΩ, 1/4W, ± 5%, Carbon	1		
R103	**ERD25TJ682**	6.8kΩ, 1/4W, ± 5%, Carbon	1		
R104	**ERD25TJ102**	1kΩ, 1/4W, ± 5%, Carbon	1		
R105	**ERD25TJ471**	470Ω, 1/4W, ± 5%, Carbon	1		
R106	**ERD25TJ101**	100Ω, 1/4W, ± 5%, Carbon	1		

Ref. No.	Part No.	Part Name & Description	Per Set		Remarks
R107	**ERD25TJ103**	10kΩ, 1/4W, ± 5%, Carbon	1		
R108	**ERD25TJ152**	1.5kΩ, 1/4W, ± 5%, Carbon	1		
R109	**ERD25TJ104**	100kΩ, 1/4W, ± 5%, Carbon	1		
R110	**ERD25TJ471**	470Ω, 1/4W, ± 5%, Carobn	1		
R111	**ERD25TJ823**	82kΩ, 1/4W, ± 5%, Carbon	1		
R112	**ERD25TJ104**	100kΩ, 1/4W, ± 5%, Carbon	1		
R113	**ERD25TJ473**	47kΩ, 1/4W, ± 5%, Carbon	1		
R114	**ERD25TJ221**	220Ω, 1/4W, ± 5%, Carbon	1		
R115	**ERD25TJ104**	100kΩ, 1/4W, ± 5%, Carbon	1		
R116	**ERD25TJ682**	6.8kΩ, 1/4W, ± 5%, Carbon	1		
R117	**ERD25TJ562**	5.6kΩ, 1/4W, ± 5%, Carbon	1		
R118	**ERD25TJ272**	2.7kΩ, 1/4W, ± 5%, Carbon	1		
R119	**ERD25TJ101**	100Ω, 1/4W, ± 5%, Carbon	1		
R120	**ERD25TJ222**	2.2kΩ, 1/4W, ± 5%, Carbon	1		
R121	**ERD25TJ473**	47kΩ, 1/4W, ± 5%, Carbon	1		
R122	**ERD25TJ823**	82kΩ, 1/4W, ± 5%, Carbon	1		
R123	**ERD25TJ153**	15kΩ, 1/4W, ± 5%, Carbon	1		
R124	**ERD25TJ102**	1kΩ, 1/4W, ± 5%, Carbon	1		
R125	**ERD25TJ331**	330Ω, 1/4W, ± 5%, Carbon	1		
R126	**ERD25TJ104**	100kΩ, 1/4W, ± 5%, Carbon	1		
R127	**ERD25TJ562**	5.6kΩ, 1/4W, ± 5%, Carbon	1		
R128	**ERD25TJ562**	5.6kΩ, 1/4W, ± 5%, Carbon	1		
R129	**ERD25TJ682**	6.8kΩ, 1/4W, ± 5%, Carbon	1		
R130	**ERD25TJ682**	6.8kΩ, 1/4W, ± 5%, Carbon	1		
R131	**ERD25TJ472**	4.7kΩ, 1/4W, ± 5%, Carbon	1		
R132	**ERD25TJ472**	4.7kΩ, 1/4W, ± 5%, Carbon	1		
R133	**ERD25TJ561**	560Ω, 1/4W, ± 5%, Carbon	1		
R134	**ERD25TJ561**	560Ω, 1/4W, ± 5%, Carbon	1		
R135	**ERD25TJ472**	4.7kΩ, 1/4W, ± 5%, Carbon	1		
R136	**ERD25TJ472**	4.7kΩ, 1/4W, ± 5%, Carbon	1		
R137	**ERD25TJ473**	47kΩ, 1/4W, ± 5%, Carbon	1		
R138	**ERD25TJ473**	47kΩ, 1/4W, ± 5%, Carbon	1		
R139	**ERD25TJ101**	100Ω, 1/4W, ± 5%, Carbon	1		
R140	**ERD25TJ824**	820kΩ, 1/4W, ± 5%, Carbon	1		
R141	ERD12FJ471	470Ω, 1/2W, ± 5%, Carbon	1		
R142	**ERG1ANJ331**	330Ω, 1W, ± 5%, Metallic	1		
R143	ERD12FJ471	470Ω, 1/2W, ± 5%, Carbon	1		
R144	**ERD25TJ151**	150Ω, 1/4W, ± 5%, Carbon	1		
R145	**ERD25TJ100**	10Ω, 1/4W, ± 5%, Carbon	1		
R146	**ERD25TJ332**	3.3kΩ, 1/4W, ± 5%, Carbon	1		
R147	**ERD25TJ100**	10Ω, 1/4W, ± 5%, Carbon	1		
R148	**ERD25TJ473**	47kΩ, 1/4W, ± 5%, Carbon	1		
R149	**ERD25TJ153**	15kΩ, 1/4W, ± 5%, Carbon	1		
R150	**ERD25TJ473**	47kΩ, 1/4W, ± 5%, Carbon	1		
R151	**ERD25TJ104**	100kΩ, 1/4W, ± 5%, Carbon	1		
R152	**ERD25TJ123**	12kΩ, 1/4W, ± 5%, Carbon	1		
R153	**ERD25TJ273**	27kΩ, 1/4W, ± 5%, Carobn	1		
R154	**ERD25TJ104**	100kΩ, 1/4W, ± 5%, Carbon	1		
R201	ERD12TSJ274	270kΩ, 1/2W, ± 5%, Carbon	1		
R202	ERD12TSJ274	270kΩ, 1/2W, ± 5%, Carbon	1		
R203	**ERD25TJ331**	330Ω, 1/4W, ± 5%, Carbon	1		
R204	**ERD25TJ331**	330Ω, 1/4W, ± 5%, Carbon	1		
R205	ERD12TSJ334	330kΩ, 1/2W, ± 5%, Carbon	1		
R206	ERD12TSJ334	330kΩ, 1/2W, ± 5%, Carbon	1		
R207	**ERD25TJ103**	10kΩ, 1/4W, ± 5%, Carbon	1		
R208	**ERD25TJ103**	10kΩ, 1/4W, ± 5%, Carbon	1		
R209	ERO50CKF1743	174kΩ, 1/2W, ± 1%, Metallic	1		O
R210	ERO50CKF1743	174kΩ, 1/2W, ± 1%, Metallic	1		O
R213	ERO50CKF1502	15kΩ, 1/2W, ± 1%, Metallic	1		O
R214	ERO50CKF1502	15kΩ, 1/2W, ± 1%, Metallic	1		O

Ref. No	Part No.	Part Name & Description	Per Set	Remarks
R215	**ERD25TJ104**	100kΩ, 1/4W, ± 5%, Carbon	1	
R216	**ERD25TJ104**	100kΩ, 1/4W, ± 5%, Carbon	1	
R217	ERD12TSJ563	56kΩ, 1/2W, ± 5%, Carbon	1	
R218	ERD12TSJ563	56kΩ, 1/2W, ± 5%, Carbon	1	
R219	**ERD25TJ101**	100Ω, 1/4W, ± 5%, Carbon	1	
R220	**ERD25TJ101**	100Ω, 1/4W, ± 5%, Carbon	1	
R221	**ERD25TJ331**	330Ω, 1/4W, ± 5%, Carbon	1	
R222	**ERD25TJ331**	330Ω, 1/4W, ± 5%, Carbon	1	
R223	**ERD14FJ102**	1kΩ, 1/4W, ± 5%, Carbon	1	
R501	**ERD25TJ394**	390kΩ, 1/4W, ± 5%, Carbon	1	
R502	**ERD25TJ394**	390kΩ, 1/4W, ± 5%, Carbon	1	
R503	**ERD25TJ102**	1kΩ, 1/4W, ± 5%, Carbon	1	
R504	**ERD25TJ102**	1kΩ, 1/4W, ± 5%, Carbon	1	
R505	**ERD25TJ393**	39kΩ, 1/4W, ± 5%, Carbon	1	
R506	**ERD25TJ393**	39kΩ, 1/4W, ± 5%, Carbon	1	
R507	**ERD25TJ392**	3.9kΩ, 1/4W, ± 5%, Carbon	1	
R508	**ERD25TJ392**	3.9kΩ, 1/4W, ± 5%, Carbon	1	
R509	**ERD25TJ823**	82kΩ, 1/4W, ± 5%, Carbon	1	
R510	**ERD25TJ823**	82kΩ, 1/4W, ± 5%, Carbon	1	
R511	**ERD25TJ332**	3.3kΩ, 1/4W, ± 5%, Carbon	1	
R512	**ERD25TJ332**	3.3kΩ, 1/4W ± 5%, Carbon	1	
R513	**ERD25TJ391**	390Ω, 1/4W, ± 5%, Carbon	1	
R514	**ERD25TJ391**	390Ω, 1/4W, ± 5%, Carbon	1	
R515	**ERD25TJ103**	10kΩ, 1/4W, ± 5%, Carbon	1	
R516	**ERD25TJ103**	10kΩ, 1/4W, ± 5%, Carbon	1	
R517	**ERD25TJ153**	15kΩ, 1/4W, ± 5%, Carbon	1	
R518	**ERD25TJ153**	15kΩ, 1/4W, ± 5%, Carbon	1	
R519	**ERD25TJ122**	1.2kΩ, 1/4W, ± 5%, Carbon	1	
R520	**ERD25TJ122**	1.2kΩ, 1/4W, ± 5%, Carbon	1	
R521	**ERD25TJ103**	10kΩ, 1/4W, ± 5%, Carbon	1	
R522	**ERD25TJ103**	10kΩ, 1/4W, ± 5%, Carbon	1	
R523	**ERD25TJ394**	390kΩ, 1/4W, ± 5%, Carbon	1	
R524	**ERD25TJ394**	390kΩ, 1/4W, ± 5%, Carbon	1	
R525	**ERD25TJ563**	56kΩ, 1/4W, ± 5%, Carbon	1	
R526	**ERD25TJ563**	56kΩ, 1/4W, ± 5%, Carbon	1	
R527	**ERD25TJ822**	8.2kΩ, 1/4W, ± 5%, Carbon	1	
R528	**ERD25TJ822**	8.2kΩ, 1/4W, ± 5%, Carbon	1	
R529	**ERD25TJ272**	2.7kΩ, 1/4W, ± 5%, Carbon	1	
R530	**ERD25TJ272**	2.7kΩ, 1/4W, ± 5%, Carbon	1	
R531	**ERD25TJ683**	68kΩ, 1/4W, ± 5%, Carbon	1	
R532	**ERD25TJ683**	68kΩ, 1/4W, ± 5%, Carbon	1	
R533	**ERD25TJ272**	2.7kΩ, 1/4W, ± 5%, Carbon	1	
R534	**ERD25TJ272**	2.7kΩ, 1/4W, ± 5%, Carbon	1	
R535	**ERD25TJ562**	5.6kΩ, 1/4W, ± 5%, Carbon	1	
R536	**ERD25TJ562**	5.6kΩ, 1/4W, ± 5%, Carbon	1	
R537	**ERD14FJ102**	1kΩ, 1/4W, ± 5%, Carbon	1	
R601	**ERD25TJ824**	820kΩ, 1/4W, ± 5%, Carbon	1	
R602	**ERD25TJ824**	820kΩ, 1/4W, ± 5%, Carbon	1	
R603	**ERD25TJ102**	1kΩ, 1/4W, ± 5%, Carbon	1	
R604	**ERD25TJ102**	1kΩ, 1/4W, ± 5%, Carbon	1	
R605	**ERD25TJ563**	56kΩ, 1/4W, ± 5%, Carbon	1	
R606	**ERD25TJ563**	56kΩ, 1/4W, ± 5%, Carbon	1	
R607	**ERD25TJ153**	15kΩ, 1/4W, ± 5%, Carbon	1	
R608	**ERD25TJ153**	15kΩ, 1/4W, ± 5%, Carbon	1	
R609	**ERD25TJ102**	1kΩ, 1/4W, ± 5%, Carbon	1	
R610	**ERD25TJ102**	1kΩ, 1/4W, ± 5%, Carbon	1	
R611	**ERD25TJ102**	1kΩ, 1/4W, ± 5%, Carbon	1	
R612	**ERD25TJ102**	1kΩ, 1/4W, ± 5%, Carbon	1	
R613	**ERD25TJ182**	1.8kΩ, 1/4W, ± 5%, Carbon	1	

Ref. No.	Part No.	Part Name & Description	Per Set	Remarks
R614	**ERD25TJ182**	1.8kΩ, 1/4W, ± 5%, Carbon	1	
R615	**ERD25TJ104**	100kΩ, 1/4W, ± 5%, Carbon	1	
R616	**ERD25TJ104**	100kΩ, 1/4W, ± 5%, Carbon	1	
R617	**ERG1ANJ152**	1.5kΩ, 1W, ± 5%, Metallic	1	
R618	**ERG1ANJ152**	1.5kΩ, 1W, ± 5%, Metallic	1	
R619	ERD12FJ472	4.7kΩ, 1/2W, ± 5%, Carbon	1	
R620	ERD12FJ472	4.7kΩ, 1/2W, ± 5%, Carbon	1	
R621	**ERD25TJ471**	470Ω, 1/4W, ± 5%, Carbon	1	
R622	**ERD25TJ471**	470Ω, 1/4W, ± 5%, Carbon	1	
R623	**ERD25TJ152**	1.5kΩ, 1/4W, ± 5%, Carbon	1	
R624	**ERD25TJ152**	1.5kΩ, 1/4W, ± 5%, Carbon	1	
R625	**ERD14FJ681**	680Ω, 1/4W, ± 5%, Carbon	1	
R626	**ERD14FJ681**	680Ω, 1/4W, ± 5%, Carbon	1	
R627	**ERD14FJ100**	10Ω, 1/4W, ± 5%, Carbon	1	
R628	**ERD14FJ100**	10Ω, 1/4W, ± 5%, Carbon	1	
R629	**ERD14FJ101**	100Ω, 1/4W, ± 5%, Carbon	1	
R630	**ERD14FJ101**	100Ω, 1/4W, ± 5%, Carbon	1	
R631	**ERD14FJ470**	47Ω, 1/4W, ± 5%, Carbon	1	
R632	**ERD14FJ470**	47Ω, 1/4W, ± 5%, Carbon	1	
R633	**ERD14FJ330**	33Ω, 1/4W, ± 5%, Carbon	1	
R634	**ERD14FJ330**	33Ω, 1/4W, ± 5%, Carbon	1	
R635	**ERD14FJ330**	33Ω, 1/4W, ± 5%, Carbon	1	
R636	**ERD14FJ330**	33Ω, 1/4W, ± 5%, Carbon	1	
R637	**ERD14FJ331**	330Ω, 1/4W, ± 5%, Carbon	1	
R638	**ERD14FJ331**	330Ω, 1/4W, ± 5%, Carbon	1	
R639	ERF5AKR47	0.47Ω, 5W, ±10%, Non-Flammable	1	
R640	ERF5AKR47	0.47Ω, 5W, ±10%, Non-Flammable	1	
R641	ERF5AKR47	0.47Ω, 5W, ±10%, Non-Flammable	1	
R642	ERF5AKR47	0.47Ω, 5W, ±10%, Non-Flammable	1	
R643	**ERD25TJ104**	100kΩ, 1/4W, ± 5%, Carbon	1	
R644	**ERD25TJ104**	100kΩ, 1/4W, ± 5%, Carbon	1	
R645	**ERD25TJ563**	56kΩ, 1/4W, ± 5%, Carbon	1	
R646	**ERD25TJ563**	56kΩ, 1/4W, ± 5%, Carbon	1	
R647	**ERG2ANJ331**	330Ω, 2W, ± 5%, Metallic	1	
R648	**ERG2ANJ331**	330Ω, 2W, ± 5%, Metallic	1	
R649	**ERX2ANJ100**	10Ω, 2W, ± 5%, Metallic	1	
R650	**ERX2ANJ100**	10Ω, 2W, ± 5%, Metallic	1	
R651	ERD12FJ272	2.7kΩ, 1/2W, ± 5%, Carbon	1	
R652	**ERG2ANJ102**	1kΩ, 2W, ± 5%, Metallic	1	
R653	**ERD25TJ153**	15kΩ, 1/4W, ± 5%, Carbon	1	
R654	**ERD25TJ822**	8.2kΩ, 1/4W, ± 5%, Carbon	1	
R655	**ERD25TJ393**	39kΩ, 1/4W, ± 5%, Carbon	1	
R656	**ERD25TJ333**	33kΩ, 1/4W, ± 5%, Carbon	1	
R657	**ERD25TJ564**	560kΩ, 1/4W, ± 5%, Carbon	1	
R658	**ERD25TJ333**	33kΩ, 1/4W, ± 5%, Carbon	1	
R659	**ERD25TJ472**	4.7kΩ, 1/4W, ± 5%, Carbon	1	
	Resistors, only Set for England [XE]			
R660 [XE]	**ERD25TJ393**	39kΩ, 1/4W, ± 5%, Carbon	1	
R661 [XE]	**ERD25TJ123**	12kΩ, 1/4W, ± 5%, Carbon	1	
R662 [XE]	**ERD25TJ563**	56kΩ, 1/4W, ± 5%, Carbon	1	
R663 [XE]	**ERD25TJ824**	820kΩ, 1/4W, ± 5%, Carbon	1	
R664 [XE]	**ERD25TJ124**	120kΩ, 1/4W, ± 5%, Carbon	1	
R665 [XE]	**ERD25TJ124**	120kΩ, 1/4W, ± 5%, Carbon	1	
R666 [XE]	**ERD25TJ563**	56kΩ, 1/4W, ± 5%, Carbon	1	

■ CABINET & CHASSIS PARTS



Ref. No.	Part No.	Part Name & Description	Per Set		Remarks
R703	**ERG3ANJ181**	180Ω, 3W, ± 5%, Metallic	1		
R704	**ERD14FJ122**	1.2kΩ, 1/4W, ± 5%, Carbon	1		
R705	**ERD25TJ153**	15kΩ, 1/4W, ± 5%, Carbon	1		
R1003	**ERD25TJ102**	1kΩ, 1/4W, ± 5%, Carbon	1		
R1004	**ERD25TJ102**	1kΩ, 1/4W, ± 5%, Carbon	1		
R1005	**ERD25TJ102**	1kΩ, 1/4W, ± 5%, Carbon	1		
R1006	**ERD25TJ102**	1kΩ, 1/4W, ± 5%, Carbon	1		
R1007	**ERD25TJ123**	12kΩ, 1/4W, ± 5%, Carbon	1		
R1008	**ERD25TJ123**	12kΩ, 1/4W, ± 5%, Carbon	1		
R1009	**ERD25TJ824**	820kΩ, 1/4W, ± 5%, Carbon	1		
R1010	**ERD25TJ824**	820kΩ, 1/4W, ± 5%, Carbon	1		
R1011	**ERD25TJ105**	1MΩ, 1/4W, ± 5%, Carbon	1		
R1012	**ERD25TJ105**	1MΩ, 1/4W, ± 5%, Carbon	1		
R1013	**ERD25TJ104**	100kΩ, 1/4W, ± 5%, Carbon	1		
R1014	**ERD25TJ104**	100kΩ, 1/4W, ± 5%, Carbon	1		
R1015	**ERD25TJ474**	470kΩ, 1/4W, ± 5%, Carbon	1		
R1016	**ERD25TJ474**	470kΩ, 1/4W, ± 5%, Carbon	1		
R1017	**ERD25TJ472**	4.7kΩ, 1/4W, ± 5%, Carbon	1		
R1018	**ERD25TJ472**	4.7kΩ, 1/4W, ± 5%, Carbon	1		
R1019	**ERD25TJ472**	4.7kΩ, 1/4W, ± 5%, Carbon	1		
R1020	**ERD25TJ472**	4.7kΩ, 1/4W, ± 5%, Carbon	1		
VARIABLE RESISTORS					
VR101	EVLS0AA00B55	500kΩ (B), Muting Level Adjustment	1		
VR102	EVLS3AA00B14	10kΩ (B), PLL VCO Adjustment	1		
VR103	EVLS3AA00B24	20kΩ (B) Separation Adjustment	1		
VR104	EVLS3AA00B24	20kΩ (B), FM Signal Meter Adjustment	1		
VR501, 502	EWF2QAF30B15	100kΩ (B), Bass & Treble Control	2		
VR601, 602	EVLS3AA00B52	500Ω (B), Main Amp Ico Adjustment	2		
VR1001	EWF5MA037BF5	250kΩ (B), Volume Control	1		○
VR1002	EVE7DA088G25	200kΩ (G), Balance Control	1		○
CAPACITORS					
C1	ECCD1H120KC	12pF, 50WV, ±10%, Ceramic	1		
C2	ECCD1H0101CC	1pF, 50WV, ±0.25pF, Ceramic	1		
C3	ECCD1H180KR	18pF, 50WV, ±10%, Ceramic	1		
C4	ECKD1H102MDA	0.001μF, 50WV, ±20%, Ceramic	1		
C5	ECCD1H100KC	10pF, 50WV, ±10%, Ceramic	1		
C6	ECCD1H181K	180pF, 50WV, ±10%, Ceramic	1		
C7	ECKD1H102PF	0.001μF, 50WV, +100% −0% Ceramic	1		
C9	ECKD1H103PF	0.01μF, 50WV, +100% −0% Ceramic	1		
C10	ECKD1H102PF	0.001μF, 50WV, +100% −0% Ceramic	1		
C11	ECCD1H180KC	18pF, 50WV, ±10%, Ceramic	1		
C12	ECCD1H390KC	39pF, 50WV, ±10%, Ceramic	1		
C13	ECCD1H100KC	10pF, 50WV, ±10%, Ceramic	1		
C14	ECCD1H220KR	22pF, 50WV, ±10%, Ceramic	1		
C15	ECCD1H010CC	1pF, 50WV, ±0.25pF, Ceramic	1		
C16	ECCD1H070DC	7pF, 50WV, ±0.5pF, Ceramic	1		
C17	ECCD1H180KC	18pF, 50WV, ±10%, Ceramic	1		
C18	ECQS1361JZ	360pF, 125WV, ±5%, Styrol	1		
C19	ECKD1H103MD	0.01μF, 50WV, ±20%, Ceramic	1		
C20	ECKD1H103MD	0.01μF, 50WV, ±20%, Ceramic	1		
C21	ECKD1H103PF	0.01μF, 50WV, +100% −0% Ceramic	1		
C22	**ECEA16V10V**	10μF, 16WV, Electrolytic	1		
C23	ECKD1H103PF	0.01μF, 50WV, +100% −0% Ceramic	1		
C24	**ECEA16V10V**	10μF, 16WV, Electrolytic	1		
C25	ECKD1H103PF	0.01μF, 50WV, +100% −0% Cermaic	1		

Ref. No.	Part No.	Part Name & Description	Per Set		Remarks
C26	ECKD1H102PF	0.001μF, 50WV, +100% −0% Ceramic	1		
C27	**ECEA50V3R3V**	3.3μF, 50WV, Electrolytic	1		
C28	**ECEA50V3R3V**	3.3μF, 50WV, Electrolytic	1		
C29	**ECEA50V1V**	1μF, 50WV, Electrolytic	1		
C30	ECQM05223KZ	0.022μF, 50WV, ±10%, Polyester	1		
C31	ECQM05473KZ	0.047μF, 50WV, ±10%, Polyester	1		
C101	ECKD1H103PF	0.01μF, 50WV, +100% −0% Ceramic	1		
C102	ECCD1H180KC	18pF 50WV, ±10% Ceramic	1		
C103	ECKD1H103PF	0.01μF, 50WV, +100% −0% Ceramic	1		
C104	ECKD1H102PF	0.001μF, 50WV, +100% −0% Ceramic	1		
C105	ECKD1H223PF	0.022μF, 50WV, +100% −0% Ceramic	1		
C106	**ECEA16V10V**	10μF, 16WV, Electrolytic	1		
C107	**ECEA50V1V**	1μF, 50WV, Electrolytic	1		
C108	ECKD1H103MD	0.01μF, 50WV, ±20% Ceramic	1		
C109	ECKD1H103MD	0.01μF, 50WV, ±20%, Ceramic	1		
C110	**ECEA50ZR1**	0.1μF, 50WV, Electrolytic	1		
C111	ECCD1H101K	100pF, 50WV, ±10%, Ceramic	1		
C112	**ECEA50VR47V**	0.47μF, 50WV, Electrolytic	1		
C113	ECKD1H103PF	0.01μF, 50WV, +100% −0% Ceramic	1		
C114	ECKD1H103PF	0.01μF, 50WV, +100% −0% Ceramic	1		
C115	ECKD1H103PF	0.01μF, 50WV, +100% −0% Ceramic	1		
C116	ECKD1H102PF	0.001μF, 50WV, +100% −0% Ceramic	1		
C117	ECKD1H103PF	0.01μF, 50WV, +100% −0% Ceramic	1		
C118	**ECEA6V220V**	220μF, 6.3WV, Electrolytic	1		
C119	**ECEA35V4R7V**	4.7μF, 35WV, Electrolytic	1		
C120	ECQM05473KZ	0.047μF, 50WV, ±10%, Polyester	1		
C121	ECQS1471JZ-K	470pF, 125WV, ±5%, Styrol	1		
C122	**ECEA50ZR22**	0.22μF, 50WV, Electrolytic	1		
C123	**ECEA50VR47V**	0.47μF, 50WV, Electrolytic	1		
C124	ECKD1H102PF	0.001μF, 50WV, +100% −0% Ceramic	1		
C125	ECEA50MR22R	0.22μF, 50WV, Electrolytic	1		
C126	**ECEA35V4R7V**	4.7μF, 35WV, Electrolytic	1		
C127	ECQM05123JZ	0.012μF, 50WV, ±5%, Polyester	1		
C128	ECQM05123JZ	0.012μF, 50WV, ±5%, Polyester	1		
C129	**ECEA50ZR33**	0.33μF, 50WV, Electrolytic	1		
C130	**ECEA50ZR33**	0.33μF, 50WV, Electrolytic	1		
C131	**ECEA16V47V**	47μF, 16WV, Electrolytic	1		
C132	ECQM05153KZ	0.015μF, 50WV, ±10%, Polyester	1		
C133	**ECEA16V220V**	220μF, 16WV, Electrolytic	1		
C134	ECKD1H103PF	0.01μF, 50WV, +100% −0% Ceramic	1		
C135	ECKD1H103PF	0.01μF, 50WV, +100% −0% Ceramic	1		
C136	**ECEA16V47V**	47μF, 16WV, Electrolytic	1		
C137	**ECEA50V3R3V**	3.3μF, 50WV, Electrolytic	1		
C138	**ECEA50VR47V**	0.47μF, 50WV, Electrolytic	1		
C139	ECQM05223KZ	0.022μF, 50WV, ±10%, Polyester	1		
C140	ECQM05223KZ	0.022μF, 50WV, ±10%, Polyester	1		
C141	ECCD1H010CC	1pF, 50WV, ±0.25pF, Ceramic	1		
C142	ECKD1H223PF	0.022μF, 50WV, +100% −0% Ceramic	1		
C201	ECCD1H151K	150pF, 50WV, ±10%, Ceramic	1		
C202	ECCD1H151K	150pF, 50WV, ±10%, Ceramic	1		
C203	ECEA50M3R3R	3.3μF, 50WV, Electrolytic	1		
C204	ECEA50M3R3R	3.3μF, 50WV, Electrolytic	1		
C205	ECCD1H680K	68pF, 50WV, ±10%, Ceramic	1		
C206	ECCD1H680K	68pF, 50WV, ±10%, Ceramic	1		
C207	ECKD2H681KB	680pF, 500WV, ±10%, Cermaic	1		
C208	ECKD2H681KB	680pF, 500WV, ±10%, Ceramic	1		
C209	**ECEA6V330V**	330μF, 6.3WV, Electrolytic	1		
C210	**ECEA6V330V**	330μF, 6.3WV, Electrolytic	1		
C211	ECQF1183GZN	0.018μF, 125WV, ±2%, Polypropylene	1		○

Ref. No.	Part No.	Part Name & Description	Per Set		Remarks
C212	ECQF1183GZN	0.018μF, 125WV, ±2%, Polypropylene	1		○
C213	ECQF1472GZN	0.0047μF, 125WV, ±2%, Polypropylene	1		○
C214	ECQF1472GZN	0.0047μF, 125WV, ±2%, Polypropylene	1		○
C215	ECEA50M1R	1μF, 50WV, Electrolytic	1		
C216	ECEA50M1R	1μF, 50WV, Electrolytic	1		
C217	**ECEA50V220V**	220μF, 50WV, Electrolytic	1		
C219	ECKD2H391KB	390pF, 500WV, ±10%, Ceramic	1		
C220	ECKD2H391KB	390pF, 500WV, ±10%, Ceramic	1		
C501	ECEA50MR68R	0.68μF, 50WV, Electrolytic	1		
C502	ECEA50MR68R	0.68μF, 50WV, Electrolytic	1		
C503	ECKD2H331KB	330pF, 500WV, ±10%, Ceramic	1		
C504	ECKD2H331KB	330pF, 500WV, ±10%, Ceramic	1		
C505	ECEA50M3R3R	3.3μF, 50WV, Electrolytic	1		
C506	ECEA50M3R3R	3.3μF, 50WV, Electrolytic	1		
C507	ECQM05223KZ	0.022μF, 50WV, ±10%, Polyester	1		
C508	ECQM05223KZ	0.022μF, 50WV, ±10%, Polyester	1		
C509	ECQM05223KZ	0.022μF, 50WV, ±10%, Polyester	1		
C510	ECQM05223KZ	0.022μF, 50WV, ±10%, Polyester	1		
C511	ECQM05222KZ	0.0022μF, 50WV, ±10%, Polyester	1		
C512	ECQM05222KZ	0.0022μF, 50WV, ±10%, Polyester	1		
C513	ECEA50MR68R	0.68μF, 50WV, Electrolytic	1		
C514	ECEA50MR68R	0.68μF, 50WV, Electrolytic	1		
C515	ECCD1H220K	22pF, 50WV, ±10%, Ceramic	1		
C516	ECCD1H220K	22pF, 50WV, ±10%, Ceramic	1		
C517	**ECEA16V47V**	47μF, 16WV, Electrolytic	1		
C518	**ECEA16V47V**	47μF, 16WV, Electrolytic	1		
C519	ECEA50M1R	1μF, 50WV, Electrolytic	1		
C520	ECEA50M1R	1μF, 50WV, Electrolytic	1		
C521	**ECEA35V220V**	220μF, 35WV, Electrolytic	1		
C601	ECEA50M1R	1μF, 50WV, Electrolytic	1		
C602	ECEA50M1R	1μF, 50WV, Electrolytic	1		
C603	**ECEA16V47V**	47μF, 16WV, Electrolytic	1		
C604	**ECEA16V47V**	47μF, 16WV, Electrolytic	1		
C607	ECCD2H180K	18pF, 500WV, ±10%, Ceramic	1		
C608	ECCD2H180K	18pF 500WV, ±10%, Ceramic	1		
C609	ECKD2H221KB	220pF, 500WV, ±10%, Ceramic	1		
C610	ECKD2H221KB	220pF, 500WV, ±10%, Ceramic	1		
C611	ECKD1H103PF	0.01μF, 50WV, +100% −0% Ceramic	1		
C612	ECKD1H103PF	0.01μF, 50WV, +100% −0% Ceramic	1		
C615	ECKD2H221KB	220pF, 500WV, Ceramic	1		
C616	ECKD2H221KB	220pF 500WV, Ceramic	1		
C617	ECCD1H050C	5pF, 50WV, ±0.25pF, Ceramic	1		
C618	ECCD1H050C	5pF, 50WV, ±0.25pF, Ceramic	1		
C619	**ECEA50V100V**	100μF, 50WV, Electrolytic	1		
C620	**ECEA50V100V**	100μF, 50WV, Electrolytic	1		
C621	**ECEA63V100V**	100μF, 63WV, Electrolytic	1		
C622	**ECEA63V100V**	100μF, 63WV, Electrolytic	1		
C623	**ECEA63V100V**	100μF, 63WV, Electrolytic	1		
C624	**ECEA63V100V**	100μF, 63WV, Electrolytic	1		
C625	**ECEA25V33V**	33μF, 25WV, Eelctrolytic	1		
C626	**ECEA16N220V**	220μF, 16WV, Non-Polar Electrolytic	1		
C627	**ECEA16V47V**	47μF, 16WV, Electrolytic	1		
C628	ECEA50M2R2R	2.2μF, 50WV, Electrolytic	1		
C629	ECKD1H103PF	0.01μF, 50WV, +100% −0% Ceramic	1		
C631	ECQM1473KZ	0.047μF, 125WV, ±10%, Polyester	1		
C632	ECQM1473KZ	0.047μF, 125WV, ±10%, Polyester	1		
C633	**ECEA63V100V**	100μF, 63WV, Electrolytic	1		
C635	**ECEA63V100V**	100μF, 63WV, Electrolytic	1		
C637	ECCD2H150D	15pF, 500WV, ±0.5pF, Ceramic	1		

Ref. No.	Part No.	Part Name & Description	Per Set		Remarks
C638	ECCD2H150D	15pF, 500WV, ±0.5pF, Ceramic	1		
C639 [XE]	**ECEA50V3R3V**	3.3μF, 50WV, Electrolytic	1		
C703	ECET63R153Y	15000μF, 63WV, Electrolytic	1		○
C704	ECET63R153Y	15000μF, 63WV, Electrolytic	1		○
C707	ECKD2H103PF	0.01μF, 500WV, +100% −0% Ceramic	1		
C708	**ECEA50V470V**	470μF, 50WV, Electrolytic	1		
C709	ECKD2H103PF	0.01μF, 500WV, +100% −0% Ceramic	1		
C710	**ECEA50V220V**	220μF, 50WV, Electrolytic	1		
C711	**ECEA35V100V**	100μF, 35WV, Electrolytic	1		
C712	ECKD1H103PF	0.01μF, 50WV, +100% −0% Ceramic	1		
C713	ECKD1H103PF	0.01μF, 50WV, +100% −0% Ceramic	1		
C714	**ECEA50V47V**	47μF, 50WV, Electrolytic	1		
C715	**ECEA35V470V**	470μF, 35WV, Electrolytic	1		
C1001	ECQM05273KZ	0.027μF, 50WV, ±10%, Polyester	1		
C1002	ECQM05273KZ	0.027μF, 50WV, ±10%, Polyester	1		
C1003	ECQM05273KZ	0.027μF, 50WV, ±10%, Polyester	1		
C1004	ECQM05273KZ	0.027μF, 50WV, ±10%, Polyester	1		
C1005	ECQM05472KZ	0.0047μF, 50WV, ±10%, Polyester	1		
C1006	ECQM05472KZ	0.0047μF, 50WV, ±10%, Polyester	1		
C1007	**ECEA50V1V**	1μF, 50WV, Electrolytic	1		
VARIABLE CAPACITOR					
CV1, 2, 3, 4, 5 (CT1, 2, 3, 4, 5)	ECV5MD34X67G	Tuning Gang, FM & AM (with Trimmer)	1		
COMPONENT COMBINATIONS					
Z701, 702	RXAF103P22HD	0.01μF (X2), Hum Cancel	2		
LAMPS					
PL1	XAMP38S150A	Lamp, Stereo Indicator (6.3V 40mA)	1		
PL2, 3, 4	XAMR54T	Lamp, Dial & Meter (12.6V, 0.38A)	3		
FUSES					
F601, 602	XBA2C40SS0	4A Fuse, Speaker Cricuit Protection	2		
F701 [X, XG, XGH, XSD, XSW, XE]	XBA2C63TR0	6.3A. T Fuse, Except Set for [XAL]	1		
F702	XBA2C20TR0	2A. T Fuse, Power Source	1		
F703	XBA2C10TR0	1A. T Fuse, Power Source	1		
F704	XBA2C31TR0	3.15A. T Fuse, Power Source	1		
SWITCHES					
S1001	SSR33	Selector Switch	1		
S1002 ~ S1007	SSH619S	Push Switches (Tape 1, 2, Mode, High-Blend, Muting & Loudness)	1		○
S1008, 1009	SSH221S	Push Switches (High & Low Filters)	1		○
S1010 [XAL]	ESB7083	Power Switch, Set for Australia [XAL]	1		○
S1010 [X, XG, XGH, XSD, XSW, XE]	ESB7075	Power Switch, Except Set for [XAL]	1		
S1011, 1012	SSH223S	Speaker Switch, Main & Remote	1		○

Ref. No.	Part No.	Part Name & Description	Per Set		Remarks
S1013 [X, XG, XGH, XSD, XSW, XE]	SSR53S	Voltage Selector Switch, Except Set for Australia [XAL]	1		
		RELAY			
RLY601	SSY13	Relay, Speakers Protection	1		
		METERS			
	SSM77	Meter, Signal	1		
	SSM79	Meter, Tuning	1		
		CABINET and CHASSIS PARTS			
1	XTS3+8CFZ	Screw, Front Panel M'tg	2		
2	SGW7370	Panel, Front	1		O
3	SBN583	Knob, Tone, Volume, Balance, Selector	5		O
4	SBN585-2	Knob, Tuning	1		O
5	XTB3+8BFZ	Screw, Chassis M'tg	23		
6	SHP641	Spacer, Front Panel	2		
7	SBC147	Button, Power Push Switch	1		
8	SGX6455	Sleeve, Push Switch Buttons	5½		O
9	SGU13	Glass Plate, Front Panel	1		O
10	SBC149	Button, Push Switches	10		
11	SHG1339	Rubber Bushing, Push Switch Buttons	10		O
12	XCJ6N11B-A	Jack, Headphones	1		
13	XNS8	Nut, Tone, Balance & Volume Control	4		
14	XWV8	Spring Washer, Tone, Balance & Volume	4		
15	XTV3+8C	Screw, Chassis M'tg	11		
16	XNS7	Nut, Selector Switch M'tg	1		
17	XNS9	Nut, Tuning Contorl M'tg	1		
18	XWV7	Spring Washer, Selector Switch	1		
19	XWV9	Spring Washer, Tuning Contorl	1		
20	SDT8007-1	Shaft, Tuning Control Ass'y	1		O
	SDX751S	Flywheel, Tuning	1		
	XXAS3K5S	Screw, Flywheel M'tg	2		
21	SXE727	Shaft, Dial Cord Ass'y	1		O
22	RDR20	Pulley, Dial Cord	4		
23	RNW150-2	Washer, Pulley Lock	4		
24	SUM7	Bracket, Dial Scale	1		O
25	SGL51	Orange Filter, Stereo Indicator	1		
26	SDH351	Plate, Dial Light	1		O
27	RHG109	Rubber Cushion, Meter	2		
28	SMMA10-2	Bracket, Meter	1		
29	XTV3+6C	Screw, Meter Bracket M'tg	1		
30	SHRA916-1	Lock Pin, Dial Scale	2		
31	SKD2570	Scale, Dial	1		O
32	SDZ6-1	Cord, Dial, 91¼" (230cm)	1 roll		
33	SDPA8	Pointer, Dial	1		
34	SHPA4	Paper, Pointer Slide	1		
35	SMP245	Reflection Board, Dial Light	1		O
36	SJF109-2	Holder, Dial Light	3		
	XRP3X5	Rivet, Dial Light Holder M'tg	3		
37	SHRA2	Spacer, FM/AM Tuner P.C.B.	1		
38	SHRA307	Clamp, Lead Wire	4		
39	SDD47-1	Drum, Dial Cord	1		
40	SDSA4121	Spring, Dial Cord	1		
41	XWC3B	Toothed Ring, P.C.B. M'tg	3		
42	SMA209	Bracket, AM Antenna Coil	1		O
	RHG109	Rubber Cushion, AM Antenna Coil	2		
43	SXE715	Shaft, Dial Cord Ass'y	1		O
44	SXE713	Shaft, Dial Cord Ass'y	1		O
45	SHGA204	Rubber Bracket, Stereo Indicator	1		
46	SKU5750	Bottom Board	1		O
47	SKL145	Foot, Set (with Lock Pin)	4		
48	SJF3015	Terminal, Input & Tape Deck	1		O
	SJS6501	Socket, Tape Deck Connector (DIN)	1		
49 [XE, XAL]	SHR131	Bushing, AC Cord, Set for [XE] & [XAL]	1		
49 [X, XG, XGH, XSD, XSW]	SHR127	Bushing, AC Cord, Set for [X], [XG], [XGH], [XSW] & [XSD]	1		
50 [XAL]	SGP330-3J	Rear Panel, Set for [XAL]	1		O
50 [XE]	SGP330-3GE	Rear Panel, Set for [XE] (with Name plate SGT12493)	1		O
50 [X, XG, XGH]	SGP330-2GX	Rear Panel, Set for [X], [XG] & [XGH] (with Name Plate SGT12490)	1		O
50 [XSD, XSW]	SGP330-2GD	Rear Panel, Set for [XSD] & [XSW] (with Name Plate SGT12491)	1		O
51 [XAL]	SJA79	AC Cord, Set for [XAL]	1		
51 [XE]	SJA73	AC Cord, Set for [XE] (Nothing AC Plug)	1		
51 [X, XG]	SJA97	AC Cord, Set for [X] & [XG]	1		
51 [XGH, XSD]	SJA81	AC Cord, Set for [XGH] & [XSD]	1		
51 [XSW]	**SJA68**	AC Cord, Set for [XSW]	1		
52	SUE3	Cover, Hole	1		
53	SJF205	Holder, Circuit Protection Fuse	1		
54	SJFA5202-1	Cover, Fuse Holder	1		
55	XSN26+12	Screw, Fuse Cover M'tg	1		
56	SHR401-1	Lock Pin, Terminal M'tg	12		
57	SJF4803-1	Terminal, Speakers	1		
58	SJFA4402	Terminal, Antenna	1		
59	XTB4+12FFZ	Screw, Cabinet M'tg	4		
60	XWG5FZ	Washer, Cabinet Screw	4		
61 [XE]	SKA8590	Cabinet, Brown Wood, Set for [XE]	1		
61 [X, XAL]	SKA8510	Cabinet, Brown Wood, Set for [X] & [XAL]	1		O
61 [XG, XGH, XSD, XSW]	SKA8511	Cabinet, Black Wood, Set for [XG], [XGH], [XSD] & [XSW]	1		O
62	SQXA4112	Caution Lable, Cabinet Screw	1		
64	XTW3+8EFZ	Screw, Rear Panel M'tg	1		
		ACCESSORIES			
A1	SSA251	Cord, 75Ω FM Antenna	1		
A2	XBA2C40SS0	4A Fuse, Speaker Circuit Protection	2		
A3	RJP5	Pin Plug	4		
A4 [X]	SJP5213	AC Plug, Only Set for [X]	1		
A5 [X]	SJP5215	AC Plug, Only Set for [X]	1		
		PACKING PARTS			
P1	SPP487	Soft Cover	1		O
P2	SPP465	Polyethylene Bag	1		
P3	SPS381-1	Pad, Left Side	1		O
P4	SPS383-1	Pad, Right Side	1		O
P5 [XE]	SPS497	Pad, Corner, Set for [XE]	4		O
P5 [X, XAL]	SPS529	Pad, Corner, Set for [X] & [XAL]	4		O
P5 [XG, XGH, XSD, XSW]	SPS533	Pad, Corner, Set for [XG], [XGH], [XSD] & [XSW]	4		O
P6 [X, XAL]	SPS477	Pad, Bottom, Set for [X] & [XAL]	1		O
P6 [XG, XGH, XSD, XSW]	SPS531	Pad, Bottom, Set for [XG], [XGH] [XSD] & [XSW] (Except Set for [XE])	1		O
P7 [X, XAL]	SPN5169	Carton Box, Inner, Set for [X] & [XAL]	1		O
P8 [X, XAL]	SPG723	Carton Box, Outer, Set for [X] & [XAL]	1		O
P8 [XE]	SPG769	Carton Box, Outer, Set for [X] & [XE]	1		O
P8 [XG, XGH, XSD, XSW]	SPG727	Carton Box, Set for [XG], [XGH], [XSD] & [XSW]	1		O
P9 [XAL]	SQF1319	Printed Matter, Only Set for [XAL]	1		O
P9 [XE]	SQF1349	Printed Matter, Only Set for [XE]	1		O
P9 [X, XG, XGH, XSD, XSW]	SQF1279	Printed Matter, Set for [X], [XG], [XGH], [XSD] & [XSW]	1		O

Notes:
Set for [X] are European, Asia, Latin America, Oceania, Middle East and Africa.
Set for [XG] are European
Set for [XGH] is Holland.
Set for [XSD] are Denmark, Sweden, Norway and Finland.
Set for [XSW] is Swiss
Set for [XAL] is Australia.
Set for [XE] is England.

■ ACCESSORIES



A4 & A5 . . . . . Set for (X)

■ PACKINGS



ORDER NO. SD7712- PT020

Parts Change Notice

FM/AM STEREO RECEIVER

SA-5560 (X),(XG),(XGH),(XSD),(XSW), (XGF),(XE),(XAL),(ES),(FE),(XM)
SA-5560A (FEE)

Re : Modification of Replacement Part

This is to advise you that part numbers of replacement parts have been changed on the following stereo models.

New part numbers (listed here in) are different from the replacement parts list of the stereo service manual.

Please revise the replacement parts list of the service manual or price list, and use new part numbers when placing replacement part orders.

Explanation of Notes : 5 7 A 1 B

Year	
5	1975
6	1976
7	1977
8	1978
•	•
•	•
•	•

Month	
1	JAN.
2	FEB.
3	MAR.
4	APR.
5	MAY.
6	JUN.
7	JUL.
8	AUG.
9	SEP.
J	OCT.
K	NOV.
L	DEC.

Interchangeability	Part	Set
A	(OLD)	(OLD)
	(NEW)	(NEW)
B	(OLD)	(OLD)
	(NEW)	(NEW)
C	(OLD)	(OLD)
	(NEW)	(NEW)
D	(OLD)	(OLD)
	(NEW)	(NEW)

Reason of Change	
1	To improve performance
2	Change of material or dimension
3	To meet approved specification
4	Standardization of parts
5	Addition of part
6	Deletion of part
7	Correction
8	Other

New Suffix of set

Notes :

How to use the interchangeability chart

- The arrows indicate which sets the part can be used in.
- For parts classified A, both the old and the new parts can be used in both the old and the new sets.
- For parts classified B, old parts cannot be used in new sets.
- For parts classified A and B, gradually new parts only should be stocked.
- For parts classified C, the use of old parts should be discontinued, for reasons of performance, etc.
- For parts classified D, both new parts and old parts should be stocked because old and new are not interchangeable.

Technics

Matsushita Electric Trading Co., Ltd.
P.O. Box 288. Central Osaka Japan
Printed in Japan
7712-6800 (K)

SA-5560(X),(XG),(XGH),(XSD),(XSW),(XGF),
(XE),(XAL),(ES),(A-FEE),(FE),(XM)

Stereo Department

Additional changes: see ↓

Refer to cover page

← Line	Description	Ref. No.	Service Manual Part No.	Notes →	Change – 1, (3) Part No.	Price	Notes →	Change – 2, (4) Part No.	Price	Line / Page	Line →
1	Resistors	R203,204	ERD18ZJ331B	6KC1	ERD25TJ102						1
2	Resistors	R209,210	ER050CK1743	72C3	ER025CKF1743						2
3	Resistors	R213,214	ER050CK1502	72C8	ER025CKF1502						3
4	Resistors	R623,624	ERD25TJ152	67C3	ERD14FJ152						4
5	Capacitor (A-FEE Only)	C2	ECCD1H0101CC	67C7	ECCD1H010CC						5
6	Meter (XG,XGH,XSD,XSW)	-------	SSM77	75C2	SSM111						6
7	Meter (XG,XGH,XSD,XSW)	-------	SSM79								7
8	Knob (XE,XG,XGH,XSD,XSW)	4	SBN585-2	68C2	SBN653S						8
9	Carton (XGF Only)	P8	Addition	76C5	SPG1255						9
10											10
11											11
12											12
13											13
14											14
15											15
16											16
17											17
18											18
19											19
20											20
21											21
22											22
23											23
24											24
25											25

For Original replacement parts list, refer to MODEL SA-5560 service manual (Order No. SD7607-1100 SD7608-1130)